



# MicroJet™

## Application Instructions

Sewer lines - Mix 1 gallon per 100 gallons water in jet vac truck. Foam sewer line prior to initial installation of *BioPlugs* and for routine maintenance of excess FOG.

Lift stations and pump stations - Mix 4 oz per gallon of water in hand held foamer unit. Spray on FOG accumulation until covered with foam.

Follow manufacturer's instructions for foaming unit.

**Storage:** Store at ambient temperature; do not allow to freeze.

**Precautions:** MSDS AVAILABLE AT [WWW.BIOSTIM.COM](http://WWW.BIOSTIM.COM)  
KEEP OUT OF REACH OF CHILDREN. PEOPLE WITH AUTOIMMUNE DEFICIENCIES SHOULD AVOID CONTACT WITH PRODUCT. In case of eye contact: flush with water for 20 minutes. In case of skin contact: wash with copious amounts of soap and water. In case of inhalation: if trouble breathing; remove to fresh air; if symptoms persist, seek medical attention immediately. In case of ingestion: drink 1-2 glasses of water to dilute; do NOT induce vomiting unless directed by physician; seek medical attention.

Copyright 2009 BioStim, LLC. All rights reserved.