



**BioStim**  
THE SCIENCE OF NATURE.

# BIOPLUG<sup>®</sup> L

For High Flow Lift Stations

**Attach BioPlug L (s) to the BioFloater. Use 1 plug per 2 inches of normal grease cap. Lower BioFloater into the lift station to approx. 1 ft. from the bottom. Tie the end of the rope to the top of the lift station.**

**Replace BioPlug L Monthly**

**Caution: KEEP OUT OF REACH OF CHILDREN**

**First Aid:** If in eyes; Flush with plenty of water for at least 15 minutes. If on skin; Wash with soap and water. If swallowed; Drink water or milk to dilute. **DO NOT** induce vomiting unless instructed by physician.