



BioStim, LLC  
PO Box 1737  
Boerne, TX 78006  
Phone (800) 338-8812  
Fax (830) 336-4827  
[www.biostim.com](http://www.biostim.com)



## OOZI FOAMER

The *Oozi Foamer* provides a thick foam for more even coating of drain lines and distribution of foam further down the drain line. This allows for extended contact time which maximizes microbial effectiveness. For use with BioStim *BioFoam*.

### Instructions:

1. Unscrew the pump assembly from the tank.
2. Fill the tank about 1/2 full with the proper mixture of water and BioStim *BioFoam*.
3. Screw the pump assembly back into the tank.
4. Twist the pump handle 1/3 of a turn counterclockwise and pump the handle.
5. Grasp trigger gun in hand, aim and squeeze the trigger.
6. Adjust foam consistency by turning the needle valve knob. Turning it counterclockwise will produce a dryer foam, while turning it clockwise will produce a wetter foam.
7. After use and before emptying or filling, remove all pressure from the unit by pulling up on the pressure relief valve.

NOTE: Silicone lubricant should be used to lube pump o-ring. Do not use oil or mineral spirits, this will damage the o-ring.

### Storage:

Do not store *Oozi Foamer* with BioStim *BioFoam* remaining in canister. Empty and rinse canister before storing.

### Precautions:

Gloves and eye protection are recommended when using BioStim *BioFoam*.

DO NOT use the same *Oozi Foamer* for *Bio* products and pesticides or chemicals.

NEVER point discharge spray towards anyone.

DEPRESSURIZE unit after use.

For more information read owner's manual received with the *Oozi Foamer* or visit the "Products" tab at [www.biostim.com](http://www.biostim.com).

